

## Basic measures of strain

### Strain in one dimension

For original length  $l_0$ , new length  $l$  angle of shear  $\psi$

**Extension** (sometimes elongation)  $e = (l-l_0)/l_0$

**Stretch**  $s = l/l_0 = 1+e$

**Quadratic elongation**  $\lambda = l^2/l_0^2 = (1+e)^2$

**Natural strain**  $\varepsilon = \ln(s) = \ln(1+e) = \ln(l/l_0)$

**Engineering shear strain**  $\gamma = \tan \psi$

**Tensor shear strain**  $e_s = 0.5 \tan \psi$

### Strain in 2 dimensions\*

Principal strains are designated by subscripts 1 and

3, e.g. principal elongations are  $e_1 > e_3$

principal stretches are  $s_1=X, s_3=Z$

**Strain ratio**  $R_s = s_1/s_3$

**Dilation**  $1+\Delta = s_1s_3$

### Fundamental strain equations (Mohr circle for strain)

For a line at an angle  $\theta$  from the  $s_1$  axis,

if  $\lambda' = l'/\lambda$  and  $\gamma' = \gamma/\lambda$  then

$$\lambda' = \frac{\lambda'_3 + \lambda'_1}{2} - \frac{\lambda'_3 - \lambda'_1}{2} \cos(2\theta)$$

$$\gamma' = \frac{\lambda'_3 - \lambda'_1}{2} \sin(2\theta)$$

If  $\lambda'$  is plotted against  $\gamma'$  these are the equations of a circle centred at

$$\lambda = \frac{\lambda'_3 + \lambda'_1}{2}, \gamma = 0 \text{ with radius } \frac{\lambda'_3 - \lambda'_1}{2}$$

### Deformation gradient tensor F

Describes relation between points in undeformed and deformed state  $\mathbf{F}\mathbf{x}_0 = \mathbf{x}$  or

$$\begin{pmatrix} a & b \\ c & d \end{pmatrix} \begin{pmatrix} x_0 \\ y_0 \end{pmatrix} = \begin{pmatrix} x \\ y \end{pmatrix}$$

where  $\mathbf{x}_0 = (x_0, y_0)$  is original location of a point and  $\mathbf{x} = (x, y)$  is final location and  $a, b, c, d$  are components of  $\mathbf{F}$ .

### Reciprocal deformation gradient tensor $\mathbf{F}^{-1}$

$$\mathbf{F}^{-1} = \frac{1}{ad-bc} \begin{pmatrix} d & -b \\ -c & a \end{pmatrix} = \begin{pmatrix} d/ad-bc & -b/ad-bc \\ -c/ad-bc & a/ad-bc \end{pmatrix}$$

This 'undoes' the deformation:  $\mathbf{F}^{-1}\mathbf{x} = \mathbf{x}_0$

**Combining deformations:** Matrix  $\mathbf{F}_c$  for two deformations  $\mathbf{F}_a$  followed by  $\mathbf{F}_b$

$$\mathbf{F}_c = \mathbf{F}_b\mathbf{F}_a$$

### Displacement gradient tensor

$$\mathbf{J} = (\mathbf{F} - \boldsymbol{\delta}) = \begin{pmatrix} a-1 & b \\ c & d-1 \end{pmatrix}$$

describes relation of displacement to position points in undeformed state:  $\mathbf{J}\mathbf{x}_0 = \mathbf{x} - \mathbf{x}_0$

### Strain tensor

$$\mathbf{E} = \begin{pmatrix} e_{xx} & e_{xz} \\ e_{zx} & e_{zz} \end{pmatrix} = \begin{pmatrix} a-1 & 0.5(b+c) \\ 0.5(b+c) & d-1 \end{pmatrix}$$

describes the non-rotational part of  $\mathbf{J}$

### Dilation

$$1+\Delta = ad-bc = |\mathbf{F}|$$

### Rotation of strain axes

Angle  $\omega$  between deformed and undeformed states

$$\tan \omega = (b-c)/(a+d)$$

### Reorientation of lines from strain ellipse

If  $\theta$  = initial orientation of a line relative to  $s_1$  and  $\theta'$  is orientation after deformation, then

$$\tan(\theta)/\tan(\theta') = R_s \text{ where } R_s \text{ is the strain ratio}$$

### Simple shear zones

If  $\gamma$  = shear strain, orientation  $\theta$  of extension axis  $s_1$  to shear-zone boundary is given by:  $\tan(2\theta) = 2/\gamma$

### Strain in 3 dimensions\*

Principal strains are designated by subscripts 1, 2 and 3, e.g. principal elongations are  $e_1 > e_2 > e_3$

Principal stretches are  $s_1=X, s_2=Y, s_3=Z$

**Dilation**  $1+\Delta = s_1s_2s_3$

**Condition for plane strain:**  $s_2=1; s_1s_3=1$

### Strain ratios for Flinn plot

$$a = s_1/s_2$$

$$b = s_2/s_3$$

Shape parameter  $k = a/b$

\*Note: the formulas are based on Ramsay, J.G., and Huber, M.I. (1983) *The Techniques of Modern Structural Geology, Volume 1: Strain Analysis*, Academic Press, London, but with sign convention modified for clockwise measurement of angles and shear strains